


Remote Programming Instructions

Remote Operation



1 Power on shutter
Listen for long BEEP

*Complete programming within 4 seconds of beep

When Motor is on Outside Left

2 Press the Program Button on back 2 times
Listen for 1 BEEP per press

3 Press up button on remote 1 time
Listen for 3 BEEP confirmation

COMPLETE
Now set limits

* If programming is incorrect for up/down, just repeat steps 2-3 for correct side

When Motor is on Outside Right

2 Press the Program Button on back 2 times
Listen for 1 BEEP per press

3 Press down button on remote 1 time
Listen for 3 BEEP confirmation

COMPLETE
Now set limits

* If programming is incorrect for up/down, just repeat steps 2-3 for correct side

Limit Setting Instructions

1 Establish Limit Directions

2 Run in down direction until Stopped to establish a 0 point

3 Turn limit using supplied tool to add / subtract limit amount

Outside Left
WHITE = UP LIMIT
RED = DOWN LIMIT

Outside Right
RED = UP LIMIT
WHITE = DOWN LIMIT

Additional Programming Instructions

Jumping programming

1 On already programmed remote or channel press program Button 2 times

2 On a new remote or new channel press program button 2 times

NEW Channel

Channel Select

COMPLETE

Factory Reset programming

1 Press P2 1 time

2 Press STOP 1 time

3 Press P2 1 time

Listen for 3 BEEP confirmation

Reset Complete